Thank you for purchasing a Screen Technics Security Cage System for the Interfit Projector Bracket, please ensure that you read the following instructions fully before attempting to install this product.

These instructions are only relevant for the Security Cage System.

PLEASE FOLLOW THESE INSTRUCTIONS TO ENSURE TROUBLE FREE OPERATION

NOTES: The Security Cage System is not suitable for installation with the 142000A flush type Projector Bracket, the Security Cage System requires at least a 100mm of post length to underside of the ceiling for fitting.

For a full list of parts please refer to the attached parts list.

STEP 1. Unscrew the thread rod inserts from the moveable uprights

STEP 2. Insert 4 of the threaded rod inserts through the corner holes on the base plate, cover the threaded rods with 4 of the moveable uprights.

STEP 3. Line the threaded rod and moveable upright assembly with the holes in top plate, using the screws and allen key tool supplied fasten the assembly in place in the four corners.

Engineered to Perform

STEP 4. Once the 4 corners have been secured turn the cage on its side and continue to insert the threaded rod through the holes and place the uprights over the rods as in the previous step in an even pattern, leaving a gap at the back of the cage to allow the projector to be fitted to the cage.

STEP 5. Make sure that the screws are only finger tight until all the uprights are in place.

STEP 6. Once all the uprights required are in place tighten all the screws.

STEP 7. Once the security cage has been constructed remove the clamp collar (pictured) from the top plate of the security cage. To remove the clamp collar please unscrew the two screws located on either side of the collar. (shown in picture)

IF THIS IS A NEW INSTALLATION PLEASE REFER TO THE INSTRUCTION INCLUDED WITH THE INTERFIT PROJECTOR BRACKET BEFORE CONTINUING WITH THE BELOW INSTRUCTIONS, FOR ALL EXISTING INSTALLATIONS PLEASE FOLLOW THE BELOW INSTRUCTIONS.

STEP 8. You will need to attach the clamp collar to the projector bracket extension pole, to do this you will need to remove the spider arm assembly holding your projector and remove the gold removable threaded ring attached to the bottom of the pole by removing the 6 screws. (Pictured right)

STEP 9. Slide the extension post through the clamp collar, once the clamp collar is in position reattach the gold removable threaded head ring.

STEP 10. Once you have determined the amount of pole that you require to protrude into the security cage allowing for the projector and the spider arm to be installed into the security cage without any difficultly, tighten the 3 grub screws on the outside of the clamp collar. Please make sure that you tighten each screw a small amount at a time and continue to tighten all 3 screws in a even pattern. This should prevent any of the screws being over tighten and will ensure that the pole is mounted centrally into the clamp collar.

STEP 11. Reattach the spider arm assembly to the extension post.

STEP 12. Once you have attached the clamp collar to the projector bracket extension post you will need to attach the security cage to the clamp collar.

AUSTRALIA 22-24 Suttor Road, Moss Vale NSW 2577 +61 2 4869 2100

NEW ZEALAND

44 Mahana Road, Te Rapa, Hamilton 0800 022 821

info@screentechnics.com.au screentechnics.com.au













Continued Over.../

SCREEN TECHNICS Engineered to Perform

STEP 13. To attach the security cage to the clamp collar you will need to slide the security cage over the spider arm assembly, projector and extension post. Once you have the security cage in place you will need to line up the holes in the clamp collar with the cut out in the L shape brackets (pictured). Thread the screws through the cut out and into the clamp collar and tighten the screws.

STEP 14. If you need to align your security cage with your projector please loosen the two screws holding the clamp collar, this will allow you to tilt the security cage and align the cage with your projector. Once you have the cage in the correct position tighten both screws and the tilt will be locked into place.

STEP 15. Once the projector and security cage has been positioned correctly insert the remaining two threaded rod and moveable upright assembly and screw them into place.

STEP 16. If any of the uprights in the security cage are interfering with the lens or cabling you can remove the uprights by unscrewing the screws on the top of the security cage and removing the threaded rod and upright covers.

STEP 17. For a professional finish you can utilize the Blank Hole Caps to fill any holes you may have in the security cages top and bottom plates from removing any of the uprights. Simply remove the rubber O-Ring first, place cap in hole and replace the O-Ring on the other side.

STEP 18. Please check all screws to make sure that they have been tightened

STEP 19. Slide the security top plate into position on the security cage and lock into position with padlock (supplied separately)

Should you have any questions regarding the installation of our projection screens please call our technical sales desk on +61 2 4869 2100 for assistance.





Security cover plate including padlock hole.





2 x large blank hole caps and 2 x small blank hole caps.

The Security Cage System is supplied as a flat pack and the following items are included in the box:



12 x Moveable Uprights with threaded rod inserts including screws.



Top plate including clamp system for projector bracket.



Base Plate